



Genuine
Accessories

REAR MUD GUARD KIT
08460-1E600/1E601

INSTALLATION INSTRUCTIONS

1. DESCRIPTION

These instruction provides a procedure to install rear mud guard on **ACCENT** vehicles.
Please read all instructions carefully before beginning installation.

2. PARTS INFORMATION

Componet	Qty
Mud Guard - Rear LH	1
Mud Guard - Rear RH	1
Screw-Tapping(A/B)	4
Retainer-Bumper Covering(C)	2



(A)

(B)



(C)



3. INSTALLATION PROCEDURE

- 1) Remove the existing screws, which secure the wheel housing (Located at A,B and C)
- 2) Attach the mudguard by inserting the tapping screws(A/B) through the guard.
- 3) Push the mudguard inward to eliminate any gap between the mudguard and the rear bumper.
- 4) Install and tighten the bumper retainer(C) as illustrated.
- 5) Repeat the above procedure for the opposite side of the vehicle.
- 6) Installation complete.