

Genuine Accessories

METAL GRAIN - CENTER FASCIA

08770-1E110/1E120

INSTALLATION INSTRUCTIONS

Supplied by HYUNDAI MOBIS

1. DESCRIPTION

These instructions provide a detailed procedure to install Metal Grain - Center Fascia for ACCENT (MC) vehicles. Carefully read all instructions prior to installation.

2. PACKAGE CONTENTS

Componet	Qty
Center Fascia	1
Instruction Sheet	1

3. INSTALLATION PROCEDURE



- 1. Remove center fascia panel from one of the corners. Tools: Pick, or flat head screwdriver.
 - NOTE: Use shop towel to protect body panel.



2. Pull center panel off.

NOTE: Center air vent duct and digital clock assembly (hazards, passenger airbag, and defrost) will come out also.



3. Plastic retainer clips may fall out.