




## The Ultimate Paint Pen




### Step 1

Make sure the stone chip surface to be touched up is clean and dry. Remove all residue (wax, rust, dirt or other).



### Step 2

**Before each application, shake well until ball flows freely inside. Remove air from pen: pointing it upwards, push tip down using cap.**




### Step 3

On a piece of cardboard, tap the tip lightly and repeatedly until paint flows out. Remove excess paint by applying to cardboard.



### Step 4

Apply a small quantity of colour at the bottom of the scratch or chipped area. More than one application might be necessary to cover the area. Wait 15 to 20 minutes between each application.



### Step 5

Before using the clearcoat side of the paint pen (15 to 20 minutes after colour application), repeat steps 2 and 3 to prepare the tip.



### Step 6

Carefully apply the clearcoat on the scratched or chipped area. **DO NOT SCRAPE** the touched up area while applying the clearcoat.

When touch up is completed, wipe tips clean and replace caps.

If one of the tips dries up or clogs, remove it from the pen and dip it in a lacquer thinner, then put it back in the pen.

This high precision paint pen has a limited warranty of 2 years.



***DANGER: Extremely flammable.  
Keep out of children's reach.  
Harmful or fatal if swallowed.***